

Automatic Humidifier Control

SEH-7100-000

by Skuttle® Indoor Air Quality Products

Safety and Installation Instructions*

INSTALLER: READ COMPLETE INSTALLATION INSTRUCTIONS BEFORE BEGINNING INSTALLATION. (Throughout this document, the terms “Compustat” and “humidifier control” are used interchangeably.)

WARNING: This product is for residential applications only, and must be installed by a qualified HVAC contractor. Failure to comply could invalidate the product warranty, or result in serious injury or electrocution.

DANGER:

- **Disconnect electrical power to the furnace before beginning installation.** Contact with a live electrical wire can cause serious injury or electrocution.
- **Use caution when cutting plenum openings and handling ductwork.** Sharp edges can cause serious cuts and bleeding.

CAUTION:


- **Do not mount Compustat on the supply duct or plenum.** The unit will not withstand supply temperatures.
- **Do not mount Compustat downstream of the bypass outlet.** Inaccurate humidity readings will cause the humidifier to operate incorrectly.
- When installing Compustat on downflow furnaces, **make sure the blower continues to run after a heat call is satisfied, to prevent high temperatures from damaging the control.**
- **Do not set the humidity so high that condensation forms on windows or walls.** Indoor condensation may result in damage to the home.

*These instructions are for installation of the Skuttle Compustat humidifier control only. For installation of a Skuttle humidifier, refer to the instructions packaged with the humidifier.

STEP 1: Check Contents of Compustat Carton

Make sure the following components are present (see Figure 1):

- Humidifier Control
- Outdoor Temperature Sensor
- Sensor Shield
- Manual Mode Faceplate
- Mounting Template



STEP 2: Disassemble the Humidifier Control


Pull the knob off, then remove the cover by inserting a screwdriver in the slot on the right side of the control.

STEP 3: Select an Interior Location and Mount the Control

Select a location to mount the humidifier control that is at least 6 inches upstream from any of the following (see Figure 2):

- Humidifier
- Humidifier Bypass Ductwork (if applicable)
- Fresh Air Intake Ductwork (if applicable)

Once a location has been selected, carefully position the humidifier control template, then drill and cut the opening. Use four sheet metal screws and the gasket (provided) to mount the control over the duct opening. Make sure the control is sealed tightly to the duct.



STEP 4: Select an Exterior Location to Mount the Outdoor Temperature Sensor

Placement of the outdoor temperature sensor must meet these requirements:

- It must be mounted on the North, Northeast or Northwest side of the house, where direct sunlight will not influence the sensor.
- It must be placed at least 3 feet from all exhaust vents.
- It must be installed above the expected snow line (see Figure 3).

CAUTION: Incorrect indoor humidity levels will result if these requirements are not met.

NOTE: For manual operation, do not install the sensor wire.

STEP 5: Locate an Existing Indoor/Outdoor Access Hole

If possible, insert the sensor cable through an existing indoor/outdoor access hole for cable TV lines, telephone lines, A/C lines, etc.

CAUTION: Make sure there are no active high-voltage wires in the hole.

As an alternative, the sensor can be mounted in the center of a 6-inch fresh air intake duct.

However, the sensor bulb must be no further than 30 inches from the outside wall. (See Figure 4.)

The sensor can also be mounted in the center of a 6 inch pipe used for make-up air or combustion make-up air devices (such as a Skuttle Model 216 or Combustion Air Diffuser). The sensor must be no further than 30 inches from the outside wall.

NOTE: If it is not possible to install the outdoor temperature sensor in any of these configurations, *Compustat* can be installed to operate manually. (See “Installing *Compustat* for Manual Operation”)

STEP 6: Route the Sensor Wire to the Selected Location

Run wire between the humidifier control and the outdoor sensor lead. If the sensor is outdoors, snap the probe end of the sensor into the sensor shield and attach it to an exterior wall. The probe must be completely covered by the shield.

NOTE: The outdoor temperature sensor wire must not exceed 30 feet in length.

CAUTION: Do not run outdoor temperature sensor wire alongside wires carrying high voltage (120 VAC or higher); do not run the sensor wire through conduit.

STEP 7: Attach the Sensor Wire to the Humidifier Control

Strip the connecting wire 1/4" and attach the two internal wires to the terminals labeled “Outdoor Temperature Sensor” on the humidifier control.

STEP 8: Select a Power Source

Select a source for 24 VAC to power the humidifier control, based on the following options:

For furnaces with accessory terminals...

- If the accessory terminals provide 24 VAC, wire them to the “24 VAC” terminals on the humidifier control.
- If the accessory terminals provide 120 VAC, wire them to a 24 VAC transformer; connect the transformer to the “24 VAC” terminals on the humidifier control.

For other furnaces, a 24 VAC transformer must be added.

- Wire into a power source other than the furnace accessory terminals. (The transformer can be powered off the 120 VAC line at the junction box, before it enters the furnace.)
- Connect the 24-volt side of the transformer to the “24 VAC” terminals on the humidifier control.

In either configuration, the voltage to the humidifier control must be between 22 and 30 VAC.

Figure 3





Figure 4



NOTE:

The humidifier control will operate properly with either a switched or continuous power source. Whether you are using accessory terminals or an external transformer, a minimum **10 VA** is required




STEP 9: Connecting to the Humidifier

Strip the wires used for all the humidifier control terminal connections 1/4".

If furnace accessory terminals are used, wire the solenoid valve directly to the “Out” terminals on the humidifier control. Also attach a jumper wire to the Wire Connector, as shown in Figures 6 and 7. Do not use a Model A50 relay.

NOTE: See the furnace manual for operation of accessory terminals.

If an external transformer is used, connect a Model A50 relay in series with the solenoid valve and the “Out” terminals on the humidifier control. This will allow the humidifier to operate only when the furnace blower is on. (See Figure 6-8 to determine the correct wiring for your model humidifier).

Figure 6**Figure 7****Figure 8**


Installing the Humidifier Control to Operate Manually

If it is not possible to use the outdoor temperature sensor, or if the homeowner wants to control the humidifier manually, *Compustat* can be reconfigured for manual operation. (See Figure 9.)

1. Locate the three-pin arrangement marked “AUTO/MAN”, protruding from the control board (directly to the right of the wiring connections).
2. Pull upward to remove the black, two-pin connector from the auto position. Reinstall it in the manual position (on the center and right-hand pins).

NOTE: Do not attach sensor wire to the blue wiring connection block.

3. Follow Steps 8 and 9 to complete the wiring. Apply the manual-mode faceplate to the *Compustat* cover. Reattach the cover to the base and reinstall the knob.



System Checkout

1. To conduct a system test, be sure that 24 VAC is applied to the 24 VAC terminals of the humidifier control.
2. Reattach the *Compustat* cover and knob to the base.
3. Activate the furnace blower and confirm that the thermostat is calling for heat.
4. Rotate the knob on the humidifier control clockwise (↻) to the “Test” position.
 - If everything is set up correctly, the humidifier should begin operating. In “Test” mode, *Compustat* will operate for approximately one minute.
 - If the humidifier does not activate properly in “Test” mode, refer to the Troubleshooting Guide, below.
5. Set the humidifier control.
 - If the home is occupied, set the humidifier control knob to “5”. (For manual operation, set the knob to “35%”.)
 - If the home is vacant, turn the humidifier control knob counterclockwise (↻) to “Off”.
6. Tell the homeowner to refer to the *Compustat* Operating Instructions for direction regarding initial adjustment.

Troubleshooting Guide

(applies to automatic and manual operation, unless otherwise indicated)

PROBLEM

Humidifier does not operate in “Test” mode

SOLUTION(S)

- Make sure the furnace blower is operating and the thermostat is calling for heat.
- Confirm that the outdoor temperature sensor is connected to the “Outdoor Temperature Sensor” terminals on the humidifier control. (For manual operation, make sure the jumper pins are positioned correctly.)
- Check the wiring diagrams (Figures 6-8) for correct installation.
- Check the voltage at the humidifier control “24 VAC” terminals. (Voltage should be between 22 and 30 VAC.)
- Check the Model A50 relay (if used) for proper installation. (The relay is to be wired to the “Out” circuit only!)
- Make sure the control knob has not been left in the “Test” position. (In “Test” mode, the humidifier will not continue to operate after approximately one minute.)

Humidifier operates only in “Test” mode

- Check the resistance of the sensor by removing the leads from the humidifier control terminals, and measuring the resistance across the wires with an ohmmeter. Compare the reading to the temperature/resistance chart, which follows.

Temperature/Resistance Chart		
100°F	6,000 ohms	38°C
90°F	7,500 ohms	32°C
80°F	9,500 ohms	27°C
70°F	11,500 ohms	21°C
60°F	14,000 ohms	16°C
50°F	18,000 ohms	10°C
40°F	23,000 ohms	4°C
30°F	28,500 ohms	-1°C
20°F	37,000 ohms	-7°C
10°F	46,500 ohms	-12°C
0°F	61,500 ohms	-18°C
-10°F	78,500 ohms	-23°C
-20°F	105,500 ohms	-29°C
-30°F	135,000 ohms	-34°C

For automatic applications...

- Make sure the outdoor temperature sensor is mounted completely outside the house (i.e., not recessed into the hole) on the North, Northeast or Northwest side, away from direct sunlight.
- Make sure the outdoor temperature sensor is mounted at least three feet away from all exhaust vents.
- If the outdoor temperature sensor is mounted in the fresh air intake duct, make sure the probe is no further than 30 inches from an outside wall.

NOTES:

In AUTOMATIC applications, if the outdoor temperature is greater than +50°F (+10°C) or less than -32°F (-35.6°C), the humidifier control will not operate (except in “Test” mode).

In both AUTOMATIC and MANUAL applications, if the relative humidity in the home is higher than the knob setting, *Compustat* will not operate the humidifier. Similarly, *Compustat* will not operate if the indoor relative humidity exceeds 45 percent.

Humidifier operates constantly

- Check the humidifier control setting. If the relative humidity in the home is less than the knob setting, the humidifier will operate until the humidity level is higher than the knob setting.
- In the “Test” mode, verify that the humidifier will shut off after approximately one minute.
- Check the resistance of the sensor. (See previous section.)

For automatic applications...

- Make sure the outdoor temperature sensor is mounted completely outside the house (i.e., not recessed into the hole) on the North, Northeast or Northwest side, away from direct sunlight.
- Turn the humidifier control knob counterclockwise (↺) to the “Off” position and observe whether the humidifier turns off. If the humidifier continues to operate, perform the following:
 - Check the wiring diagrams (Figures 5-8) for correct installation.
 - Remove the wires from the humidifier control’s “Out” terminals. If the humidifier continues to operate, check the humidifier.

Humidifier or humidifier control “chatters” or clicks on and off rapidly

- Use a voltmeter to check for a steady 22-to-30VAC.
- For automatic applications, make sure the outdoor temperature sensor wiring does not run alongside wires carrying high voltage (120 VAC or higher).



Skuttle[®]

Indoor Air Quality Products

101 Margaret Street, Marietta, OH 45750
Phone: (800) 848-9786 Fax: (740) 373-9565
Email: customerservice@skuttle.com
Web: www.skuttle.com